




Thanks a lot for your purchase and trust. We hope that your AlphaBeing air lounge meets all your expectations and bring some wonderful time for you and your friends.


### CUSTOMER SATISFACTION

We are committed to happy customer and we guarantee if the product has any manufacturing quality issue, contact us with your order number. We will send you a new replacement within 24 hours and you don't need to return the defective.

If you have some feedback on our product or experiencing any issues, please contact us via our facebook or E-mail, we'd love to hear from you. Because we rely on people like you to let us know what we are doing right and where we could improve.

● Welcome to contact us:

 <https://www.facebook.com/alphabeing.us>

 [Alphabeing@outlook.com](mailto:Alphabeing@outlook.com)

**HAPPY LOUNGIN'!**

### HOW TO SETUP

#### PRO-TIPS:

1. Run a straight line. Don't Run Around In Circles.
2. Immediately after scooping air, close the panels to prevent air escaping.
3. Open the panels immediately when you start swooping or running.



#### STEP 1

Take out AlphaBeing air lounge and unroll so it is fully extended. There are two air intake chambers on the lounge.




Be sure to open each intake, and

then stick your arm inside to separate the inner air bladder as it can stick together slightly when rolled up for extended periods of time. This allows you to capture the most amount of air with the least amount of effort.

#### STEP 2


Open one air inlet




and hold the other closed. Run a few steps in straight line rather than circle against wind to scoop air inside the first air inlet. Close the mouth before you stop running to hold the air in. Repeat running until the lounge starts to fill up. Then repeat formal steps for the other chamber.

#### STEP 3

With both chambers filled with some air, while holding the lounge ends closed, roll both chambers in the same direction to squeeze air to the pillow side until pillow is inflated. Make sure to inflate the pillow first before fully inflating air lounge.



#### STEP 4



Unroll the partially inflated air lounge and repeat step 2 to scoop more air into air lounge.

#### STEP 5

With air in the bag, start rolling closed ends tightly and neatly for at least 4-5 times until the lounge is nice and firm. Please note the 2 chambers are connected internally so they will balance each other out when the lounge is rolled.




#### STEP 6

Grab both of the plastic clips and bend them together towards the side of the lounge. You are going to make an oval with the plastic ends of the lounge. After bending the plastic pieces into the oval shape, simply secure the plastic clip together.






## HOW TO STOW



1. Open the sleeve openings and squeeze out air



2. Grab the non-sleeve opening end and tightly roll your AlphaBeing AIR SOFA



3. Find the securing buckle and pull the two ends together



4. Clip the securing buckle and make the air lounger compact



5. Put it into the pouch



6. Now it is ready to be taken anywhere

**CLEANING:** inflate your AlphaBeing inflatable lounger and gently wipe with a clean, damp cloth. DO NOT use a washing machine and/or dryer to clean it.

**MAINTENANCE:** DO NOT jump or fall into your AlphaBeing inflatable lounger. Avoid using near sharp objects. Avoid using it in direct sunlight for long periods of time. Always store away your product after use.

**WARNING:** AlphaBeing air lounger SHOULD NOT be used as a substitute safety flotation device. To avoid danger of suffocation, DO NOT LEAVE babies and children unattended with the air lounger. Always store your AlphaBeing inflatable lounger after use.

**Thank you for being our customer!**



ALPHABEING INFLATABLE LOUNGER USAGE

# INSTRUCTIONS